

# CLOSING INSTRUCTIONS

## FOR THESE LAB-BAG™ SPECIMEN SHIPPING BAGS

The specimen shipping bags in this carton are designed to perform at high internal pressure should an airliner lose its cabin pressure.

In order for the bag to perform to its design capabilities, it is imperative that the bag be closed properly after insertion of the specimen.

PLEASE FOLLOW THE PROCEDURES ILLUSTRATED BELOW



Figure 1: shows the bag laying flat on a counter with the tape side up and the tape end towards the person closing the bag



Figure 4: shows the bag after the top is folded at the slit opening and the thumbs pressing the folded end of the bag.



Figure 2: shows the specimen at the bottom of the bag and the area above the specimen being flattened in preparation for the adhesive tape to fold over.



Figure 5: shows the middle finger of both hands being used to press the adhesive together. Start at the center of the fold and work outward. Please be sure to firmly press the entire adhesive area, especially the folded edge and corners. **PRESS FIRMLY AT THE CORNER AREAS INDICATED BY THE ARROWS.**



Figure 3: shows the bag after the paper adhesive cover has been removed and with the middle fingers touching the adhesive at the middle of the bag below the slit opening. It also shows the thumbs under the end of the bag ready to fold the top of the bag over.

**This is a high performance bag.**

**Thank you for making the effort to close it properly**